


RAUCH

Phone: (718) 507-8844 Fax: (718) 565-6018
 Email: info@irauch.com
 Address: 32-20 112th St, East Elmhurst, NY 11369

Fig 333: Roller Support



Service Application:

The adjustment of the pipe line is had by turning the top nut which raises or lowers the pipe to desired pitch. The lower nut is then tightened locking support into position and prevents loosening due to vibration. To select the correct size Roller Support for use with Covered Piping and Pipe Covering Protection Saddles, refer to sizes shown in [Fig 142](#) table.

Ordering:

Order by size and figure number. Made special to customer order. Dimensions in inches.




FIG 333

PIPE SIZE	REC'M LOAD LB.	A	B	C	D	STEEL SIZE "E"	ROD G	WT/C APROX
2	400	2 7/8	6	2 7/8	1 7/8	1/4 x 1 1/4	1/2	209
2 1/2		3 3/8		3 1/4	1 15/16			243
3		4		3 5/8	2			265
3 1/2		4 1/2		4	2 1/16			272
4	600	5 1/8	6	4 5/16	2 1/4	1/4 x 1 1/2	5/8	343
5		6 1/8		5 1/16	2 3/8			426
6	900	7 1/4	6	6	2 15/16	3/8 x 2	3/4	771
8		9 3/8		7 1/4	3 1/8			993
10	1100	11 1/2	6	8 13/16	3 9/16	1/2 x 2	1	1665
12		13 1/2		10 5/16	3 7/8			1934

PROJECT INFORMATION	APPROVED
JOB:	NOTES:
ADDRESS:	
CONTRACTOR:	
ENGINEER:	
DATE:	
APPROVED _____	NOT APPROVED _____ APPROVED AS NOTED _____